



1218 50<sup>TH</sup> AVENUE PLAZA WEST,  
BRADENTON, FL34207  
TEL: 941 753 4818  
FAX: 941 755 9799  
E-MAIL: [INFO@CUSTOMCHUTES.COM](mailto:INFO@CUSTOMCHUTES.COM)

## How to use Trim zippers

Parasails are flying machines and sometimes require trimming.

The chute should fly like this, nice and straight. On occasion following a repair, having been stretched in the water or just as a result of age, it may start to fly to one side all the time; to correct this use the **Trim zippers** which are located **here**.



Close the zip 2" - 3" and fly again, keep trimming until the chute flies straight again. If the chute flies this way **trim here** or this way **trim here**.

**NEVER TOGETHER**

**NEVER SHORTEN OR TIE KNOTS IN THE LINES.**

Only use the trim zippers for trimming the chute and no other use.

